



SPICER®
Off-Highway Products

Service Manual

Axle
37RF116
43RF175

ASM-0148
January 2012



TECHNICAL DESCRIPTION

Description

The axle assembly has a spiral bevel type ring gear and pinion with further reduction provided by a planetary gear set.

Primary Reduction

The spiral bevel pinion and ring gear transmit power through the center differential pinions, side gears and planetary gear sets to the axle shafts. The spiral bevel differential assembly is mounted on tapered roller bearings, which are adjusted by the positioning of the two threaded adjusting nuts mounted in the differential carrier and cap assembly. The tapered roller pinion bearing preload is adjusted and maintained by a precision ground and hardened spacer positioned between the pinion nut and shaft shoulder.

Secondary Reduction

In the trumpet arm is a self-centering sun gear that drives four planetary gears. These gears in turn mesh with and react against a rigidly mounted internal gear. The planet gears rotate on roller bearings mounted and retained in the planet carrier, which in turn drives the axle shaft. Positive lubrication keeps all moving parts bathed in lubricant to reduce friction, heat and wear.

Internal Liquid Cooled Brakes

The multiplate liquid cooled brakes are located between the differential carrier and the trumpet arm. Reaction discs are tanged to the trumpet interior; friction discs are splined to the sun gear shaft. The hydraulically activated piston is mounted in the differential carrier. Brake torque is produced by applying hydraulic pressure to the piston, which applies axial force to the brake friction and reaction discs, generating torque at the sun gear shaft. When hydraulic pressure is released springs push the piston back releasing the brake.



FOREWORD

This manual has been prepared to provide the customer and maintenance personnel with information and instructions on the maintenance and repair of Dana Products.

Extreme care has been exercised in the design and selection of materials and manufacturing of these units. The slight outlay in personal attention and cost required to provide regular and proper lubrication, inspection at stated intervals, and such adjustments as may be indicated will be reimbursed many times in low cost operation and trouble free service.

In order to become familiar with the various parts of the product, it's principle of operation, troubleshooting, and adjustments it is urged that mechanics study the instructions in this manual carefully and use it as a reference when performing maintenance and repair operations.

Whenever repair or replacement of component parts is required, only Dana approved parts as listed in the applicable parts manual should be used. Use of "will fit" or non-approved parts may endanger proper operation and performance of the equipment. Dana does not warrant repair, replacement parts or failures resulting from the use of parts which are not supplied or approved by Dana. Important: Always furnish serial and model numbers when ordering parts.

SAFETY PRECAUTIONS

To reduce the chance of personal injury and/or property damaged, the following instructions must be carefully observed.

Proper service and repair are important to the safety of the service technician and the safe, reliable operation of the machine. If replacement parts are required the part must be replaced with a Dana specified replacement part. Do not use a replacement part of lesser quality.

The service procedures recommended in this manual are effective methods of performing service and repair. Some of these procedures require the use of purpose designed tools.

Accordingly, anyone who intends to use a replacement part, service procedure or tool which is not recommended must first determine that neither his safety or the safe operation of the machine will be jeopardized by the replacement part, service procedure or tool selected.

It is important to note that this manual contains various "Cautions and Notices" that must be carefully observed in order to reduce the risk of personal injury during service or repair. Improper service or repair may damage the unit or render it unsafe. It is important to understand that these "Cautions and Notices" are not exhaustive. It is impossible to warn of all possible hazardous consequences that may result from following or failing to follow these instructions.



TABLE OF CONTENTS

1. Technical Description
2. Forward and Caution
3. Table of Contents
5. Pad Mount Axle Without Brake - Exploded View
6. Pad Mount Axle Without Brake - Parts Description
7. Trunnion Mount Axle Without Brake - Exploded View
8. Trunnion Mount Axle Without Brake - Parts Description
9. Pad Mount Hydraloc Differential - Exploded View
10. Pad Mount Hydraloc Differential - Parts Description
11. Trunnion Mount Hydraloc Differential - Exploded View
12. Trunnion Mount Hydraloc Differential - Parts Description
13. Planetary Exploded View and Parts Description
14. Pad Mount Axle Without Brake - Cross Section
15. Trunnion Mount Axle With Brake - Cross Section
16. Hydraloc Differential - Cross Section
17. Trunnion Mounting - Cross Section
18. Hydraloc Differential Test Instructions
19. Face Seal Installation Procedure
20. Recommended Lubricants
21. Recommended Oils
22. Recommended Gear Lubricants
23. Bearing Heating and Freezing Guidelines
24. Gear Tooth Contact Chart – LH
25. Gear Tooth Contact Chart – RH
26. Cleaning and Inspection
28. Fastener Torque Chart
29. Plug Torque Chart

DISASSEMBLY

30. Trumpet Arm Removal
30. Trumpet Arm, Brake and Planetary Disassembly
36. Hydraloc Differential Disassembly
36. Drive Flange V-Ring and Wear Sleeve Removal
37. Pinion Seal Retainer Cartridge and Seal Removal
38. Differential Retainer and Adjuster Removal
41. Differential Assembly Removal
41. Ring Gear Removal
42. Differential Body Disassembly
44. Piston Removal
45. Pinion Removal
82. Trunnion Mount Removal and Disassembly



TABLE OF CONTENTS CON'T


REASSEMBLY

- 47. Hydraloc Differential Reassembly
- 52. Ring Gear Installation
- 53. Pinion Installation and Adjustment
- 56. Pinion Seal Installation
- 58. Wear Sleeve Installation
- 58. Pinion Flange Installation
- 59. Carrier Housing Assembly
- 60. Differential Assembly Installation
- 61. Differential Retainer Installation
- 62. Backlash and Contact Pattern Setup and Adjustment
- 64. Hydraloc Seal Retainer Assembly and Installation
- 67. Hydraloc Air Leakage Test
- 67. Hydraloc Hydraulic Leakage Test
- 67. Hydraloc Functional Test
- 68. Brake Piston Reassembly
- 69. Brake Air Test
- 70. Brake Piston Positioning "Clocking"
- 71. Trumpet Arm Reassembly
- 72. Face Seal Installation
- 75. Wheel Bearing Preload Setting Procedure
- 80. Trumpet Arm Installation
- 81. Axle Air Test
- 84. Trunnion Mount Reassembly and Installation

TOOL DRAWINGS

- 87. Differential Carrier Cup Drivers
- 88. Pinion Grease Seal and Washer Driver
- 89. Pinion Oil Seal Driver
- 90. Inner Lip Seal Driver
- 91. Outer Lip Seal Driver
- 92. Adjusting Nut Driver
- 93. Hydraloc Sleeve Driver
- 94. Flange Wear Sleeve Driver
- 95. Seal Retainer Installation Tool

PAD MOUNT AXLE WITHOUT BRAKE EXPLODED VIEW






PAD MOUNT AXLE WITHOUT BRAKE PARTS DESCRIPTION

ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
1	Axle Shaft	2	15	Bronze Spacer	2
2	Face Seal	2	16	Planet Carrier Assembly	2
3	Bearing Cone	2	17	Shim 0.10, 0.18, 0.25, 0.50	AR
4	Bearing Cup	2	18	Clamp Plate	2
5	Trumpet Arm Housing	2	19	Socket Head Screw	8
6	Socket Head Screw	48	20	Sun Gear	2
7	Washer	48	21	Dowel Pin	2
8	Magnetic Plug and O-Ring	2	22	Differential Carrier Assembly	1
9	O-Ring	2	23	Screw	4
10	Bearing Cup	2	24	I.D. Plate - Not Serviceable	NA
11	Bearing Cone	2			
12	Internal Ring Gear	2			
13	Dowel Pin	24			
14	Retaining Ring	2			

TRUNNION MOUNT AXLE WITH BRAKE EXPLODED VIEW






TRUNNION MOUNT AXLE WITH BRAKE PARTS DESCRIPTION

ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
1	Axle Shaft	2	27	Seal	2
2	Face Seal	2	28	Socket Head Screw	14
3	Bearing Cone	2	29	Trunnion Journal	1
4	Bearing Cup	2	30	I.D. Plate - Not Serviceable	NA
5	Trumpet Arm Housing	2	31	Screw	4
6	Socket Head Screw	48	32	Dowel Pin	2
7	Washer	62	33	Differential Carrier Assembly	1
8	O-Ring	2	34	Trunnion Sleeve	1
9	Bearing Cup	2	35	Thrust Washer	1
10	Bearing Cone	2	36	Seal	1
11	Internal Ring Gear	2	37	Rear Trunnion	1
12	Dowel Pin	24	38	Piston Inner Backup Ring	2
13	Bronze Spacer	2	39	Piston Inner Seal	2
14	Planet Carrier Assembly	2	40	Piston Outer Seal	2
15	Shim 0.10, 0.18, 0.25, 0.50	AR	41	Piston Outer Backup Ring	2
16	Clamp Plate	2	42	Piston	2
17	Socket Head Screw	8	43	Reaction Plate	2
18	Pressure Relief Valve	2	44	Friction Plate	2
19	Trunnion Cap	1	45	Sun Gear	2
20	Cap Screw	12	46	Retaining Ring	2
21	Washer	12	47	Brake Abutment	2
22	Shim .004", .007", .010", .020"	AR	48	Spring	8
23	Thrust Washer	1	49	Plug	2
24	Plug	2	50	Seat Insert	2
25	Front Trunnion	1	51	Bleeder Screw	2
26	Bushing	2	52	Magnetic Plug and O-Ring	2

PAD MOUNT HYDRALOC DIFFERENTIAL EXPLODED VIEW






PAD MOUNT HYDRALOC DIFFERENTIAL PARTS DESCRIPTION

ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
1	Socket Head Screw	1	33	Side Gear	1
2	Cap Screw	4	34	Differential Case Assembly	1
3	Seal Retainer with (2) Plugs	1	35	Case - Differential Half	1
4	Plug	1	36	Washer	12
5	Seal Ring	2	37	Capscrew	12
6	Nut - Differential Bearing Adj.	1	38	Ring Gear	1
7	Cap Screw	4	39	Housing Carrier	1
8	Retainer - Differential	1	40	Seat Insert	2
9	Plug - Tank Port	1	41	Screw - Brake Bleeder	2
9A	Plug - Pressure Port	1	42	Plug	2
10	O Ring	1	43	Nut - Differential Bearing Adj.	1
11	Cap Screw	16	44	Lock - Differential Adj. Nut	1
12	Washer	16	45	Plug - Magnetic	2
13	Seal - Outer	1	46	Pinion	1
14	Ring - Piston	2	47	Pinion Bearing Cone - Inner	1
15	Sleeve Wear	1	48	Pinion Bearing Cup - Inner	1
16	Seal Inner	1	49	Shim .004",.007",.010"	AR
17	Cup	2	50	Pinion Bearing Cone - Outer	1
18	Cone Bearing	2	51	Pinion Bearing Cup - Outer	1
19	Metric Plug - 3mm	1	52	O Ring	1
20	Flange Half	1	53	Seal - Pinion	1
21	Seal - Ring Inner	1	54	Grease Fitting	1
22	Ring - Inner Backup	1	55	Cartridge Seal Retainer	1
23	Piston	1	56	Seal - Grease	1
24	Seal - Ring Outer	1	57	Thrust Washer	1
25	Ring - Outer Backup	1	58	Seal - V Ring	1
26	Plate - Reaction	7	59	Sleeve Wear	1
27	Plate - Friction	6	60	Flange	1
28	Washers - Side Gear	2	61	O Ring	1
29	Splined Hub Gear	1	62	Spacer O Ring	1
30	Thrust Washer	4	63	Spacer Pinion	1
31	Pinon - Side Differential	4	64	Nut - Pinion Shaft	1
32	Spider - Differential	4			

TRUNNION MOUNT HYDRALOC DIFFERENTIAL EXPLODED VIEW






TRUNNION MOUNT HYDRALOC DIFFERENTIAL PARTS DESCRIPTION


ITEM	DESCRIPTION	QTY	ITEM	DESCRIPTION	QTY
1	Socket Head Screw	1	33	Pinion Gear	4
2	Cap Screw	6	34	Differential Spider	1
3	Seal Retainer	1	35	Side Gear	1
4	Plug	1	36	Differential Case Flange Half	1
5	Seal Ring	2	37	Differential Case Plain Half	2
6	Differential Bearing Adjusting Nut	1	38	Washer	12
7	Cap Screw	4	39	Cap Screw	12
8	Differential Retainer	1	40	Ring Gear	1
9	Plug	1	41	Carrier Housing	1
10	Plug	1	42	Differential Bearing Adjusting Nut	1
11	O-Ring	1	43	Differential Bearing Adj Nut Lock	1
12	Cap Screw	16	44	Magnetic Plug and O-Ring	2
13	Washer	16	45	Pinion Gear	1
14	Outer Seal	1	46	Pinion Bearing Cone	1
15	Piston Ring	2	47	Pinion Bearing Cup	1
16	Wear Sleeve	1	48	Shim .004", .007", .010"	AR
17	Inner Seal	1	49	Pinion Bearing Cup	1
18	Bearing Cup	2	50	Pinion Bearing Cone	1
19	Bearing Cone	2	51	O-Ring	1
20	3mm Plug	1	52	Pinion Seal	1
21	Cap Screw	2	53	Grease Fitting	1
22	Differential Case Cover	1	54	Seal Retainer Cartridge	1
23	Piston Inner Seal Ring	1	55	Grease Seal	1
24	Piston Inner Seal Backup Ring	1	56	Thrust Washer	1
25	Piston	1	57	V-Ring	1
26	Piston Outer Seal Ring	1	58	Wear Sleeve	1
27	Piston Outer Seal Backup Ring	1	59	Pinion Flange	1
28	Reaction Plate	7	60	O-Ring	1
29	Friction Plate	6	61	O-Ring Spacer	1
30	Side Gear Thrust Washer	2	62	Pinion Spacer	1
31	Side Gear	1	63	Pinion Shaft Nut	1
32	Pinion Gear Thrust Washer	4			

PLANETARY EXPLODED VIEW AND PARTS DESCRIPTION




ITEM	DESCRIPTION	QTY
1	Planet Carrier	1
2	Bearing	4
3	Planet Gear	4
4	Planet Gear Snap Ring	4


PAD MOUNT AXLE WITHOUT BRAKE CROSS SECTION




TRUNNION MOUNT AXLE WITH BRAKE CROSS SECTION



HYDRALOC DIFFERENTIAL CROSS SECTION



TRUNNION MOUNTING CROSS SECTION





HYDRALOC DIFFERENTIAL TEST INSTRUCTIONS

1. Air pressure test

Apply 83 kpa [12 psi] to pressure and tank ports simultaneously and allow stabilization period of 20 seconds minimum. Lock off pressure and measure decay in 10 seconds. Maximum allowable decay is 23 pa [.0033 psi] in 10 seconds. Alternate decay / period is .69 kpa [.1psi] per 5 minutes.

2. Hydraulic pressure test

Apply 4137 kpa [600 psi] to pressure port, with open tank line back to tank. Allow stabilization period of 20 seconds minimum and release. Reapply 4137 kpa [600 psi] and monitor fluid for a (1) one minute period. Fluid flow rate should not exceed 2.83 lpm [.75 gpm]

3. Functional test

Restrict movement of one side gear in differential so it will not rotate. Determine that differential is not locked by rotating input. Apply 10342 kpa [150 psi] to Hydraloc activation port. Differential should remain locked when a pinion input torque of 427 Nm [315 LBF/FT] is applied.



FACE SEAL INSTALLATION PROCEDURE

1 .	Clean trumpet arm and axle shaft with isopropyl alcohol, Quaker Solvo-Clean 68-0 or other approved evaporative solvent prior to installation of seal.
2 .	Keep original mated metal sealing rings as a set for axle shaft and trumpet arm (DO NOT INTERMIX METAL RINGS).
3 .	All parts of seal should be free of grease, oil, dirt and scale.
4 .	Sealing rings must be handled with care. Lapped sealing faces must not be damaged, scratched or contaminated with dirt or grease.
5 .	When installing the rubber toric on the seal ring, make sure that it is uniformly seated on the retaining lip and not twisted. Place the seal in the installation tool and locate assembly squarely against the housing. Use sudden and even pressure against the tool to push the toric under the retaining lip of the housing cavity. Insure the toric under the retaining lip of the trumpet arm cavity. Insure the toric is uniformly captured under the trumpet arm cavity retaining lip and is not twisted or pinched. The seal ring should be parallel to the housing within .040 [1.0 mm].
6 .	After installing the seal halves into the trumpet arm and axle shaft, wipe both metal sealing surfaces clean with lint free cloth. Then apply a coat of clean MS8 oil to the metal seal faces with a lint free applicator. Oil must not wet surfaces other than sealing faces.



RECOMMENDED LUBRICANTS FOR DRIVE AXLES

Recommendations: Extreme pressure gear lubricant is recommended for use in all drive-steer and rigid drive axles except where explicitly stated differently by Dana Off-Highway Products Engineering.

Mineral Based: Acceptable lubricants must meet **API GL-5/MT** or **MIL-PRF2105E** qualifications. The highest viscosity grade must be used given the prevailing ambient temperatures from the chart below. Limited slip designated GL-5 oil brands are preferred for quiet operating characteristics.

Universal Tractor Transmission Oils (UTTO Fluids): Acceptable lubricants must meet Dana MS266 or J. Deere J20C specifications. Use the highest viscosity grade for the ambient temperatures from the temperature chart below.

Synthetics: Synthetic lubricants are recommended providing they meet **API GL-5/MT-1** qualifications. The highest viscosity grade must be used given the prevailing ambient temperatures from the chart below. In general synthetic oils have a lower pressure viscosity response than mineral oil lubricants as the contact pressure between the gears increases. This produces a thickening of the mineral oil at the contact point. This increase in viscosity helps to maintain lubricant film thickness reducing the possibility of surface and spalling fatigue. Synthetic lubricants do not thicken as much under pressure unless specifically formulated to do so. Before using a synthetic lubricant in heavy applications, the customer must check with the lubricant supplier on the issue of high-pressure lubricant applications.

Normal Oil Change Intervals: Oil change intervals for mineral based lubricants in normal environmental and duty cycle conditions is 1000 hours in all off-highway applications and 10,000 miles in on-highway applications. Severe or sustained high operating temperature or very dusty atmospheric conditions will result in accelerated deterioration or contamination. Judgement must be used to determine the required change intervals for extreme conditions.

Extended Oil Change Interval: Extended oil service may result when using synthetic lubricants. Appropriate change intervals must be determined for each application by measuring oxidation and wear metals over time to determine a base line. Wear metal analysis can provide useful information, but an axle should not be removed from service based solely on this analysis. Vehicles, which are prone to high levels of ingested water in the axle, or water as a result of condensation, should not use extended drain intervals.

Friction Modifiers: Friction modifiers may be used with the lubricant to reduce Posi-Torq (limited slip) differential noise or liquid cooled brake noise. If friction modifiers are used, follow instructions on **TSB 278E**.

The use of aftermarket lubricant additives other than those specified is not recommended and may reduce the life of the axle and void the warranty!									
Viscosity Based on Prevailing Ambient Temperature									
UTTO – SAE 15-30									
UTTO – SAE 30									
SAE 90									
80W90									
75W90									
75W									
-40	-30	-20	-10	0	10	20	30	40	50
-40	-22	-4	14	32	50	68	86	104	122



UNIVERSAL TRACTOR TRANSAXLE OILS (UTTO) RECOMMENDED FOR DANA DRIVE AXLES

Viscosity Class: SAE 30 / SAE 20-30 / SAE 15-30 Weights

MANUFACTURER

AMOCO
AQUIP
Aral Lubricants GMBH, Bochum/D
Avia Mineralol-AG, Munchen/D
BP
BP Australia LTD, Silverwaters/AUS
BP Oil International, London/GB
BP Oil International, London/GB
Caltrex Petroleum Corp., London/GB
Case New Holland
Castrol International, Swindon/GB
Cheveron
Dea Mineralol AG, Hamburg/D
ESSO Lubricants Europe, Brussel/B
Ford
Fuchs Dea Schnierstoffe, Mannhein/D
Imperial Oil, Toronto/CDN
John Deere, Waterloo/USA
John Deere Waterloo/USA
Kuwait Petroleum, Europoor/NL
Mobil Oil Company LTD, Coryton/GB
Mobil Oil Do Brasil, Sao Paulo/BR
Mobil
Pakelo Motor Oil, San Bonifacio/I
Panolin AG, Madetswil/CH
Schwechat/A
Shell Aseol AG, Bern/CH
Shell International, London/GB
Shell
Texaco Belgium N.V., Brussels/B
Texaco
Total Fina

TRADE NAME

AMOCO1000
AQUIP Supertractor
Aral Fluid HGS
Avia N56
BP Eldoran UTH
Tractran TF-10
Tractran TF-9
Terrac Fluid 9
Caltex Textran TDH Premium
Hytrans
Castrol AGRI Powertrans
Chevron THF
Deagear TDH OMV AG
ESSO Torque Fluid 56
Ford 134D UTF
Titan Hydra J20C
Torque Fluid N56
Deere Hydgard J20-C
John Deere Hy-Gard (Europa)
Q8 T 2000
Mobilfluid 424
Mobilfluid 424
Mobil 424 UTF
Pakelo UTTO Fluid 4D
Panolin JD 303
OMV Austromatic IGB
Aseol Multitrac 85W
Shell Donax TD 80W
Shell Donax TD
Textran TDH Premium
Texaco TDH
Trac Elf C4-1000

NOTES:

- 1) The above list of oils is not meant to be an all inclusive list of acceptable oils for use in Dana products.
- 2) It is the end users responsibility to select the best grades of oils available in the local area that provide proper viscosity and limited slip friction additives for long product life and noise free operation.

API GL5 CLASS GEAR LUBRICANTS WITH LIMITED SLIP ADDITIVES RECOMMENDED FOR DANA DRIVE AXLES

Viscosity Class: SAE 75W-90 / 80W-90 / 85W-90 / 90

MANUFACTURER

Addinol Mineralol GMBH, Krump/A/D
Agip Petroli Spa, Rom/I
Aral Lubricants GMBH, Bochum/D
Avia Mineraloi-AG, Munchen/D
Baywa AG, Munchen/D
Blaser Swisslube, Hasie-Ruegsau/CH
BP Oil International, London/GB
BP Oil International, London/GB
Bucher AG, Langenthal/CH
Calpam GMBH, Aschaffenburg/D
Castrol International Swindon/GB
Castrol International Swindon/GB
Citgo USA
Citgo USA
ELF Lubricants, Paris/F
ELF Lubricants, Paris/F
ELF Lubricants, Paris/F
ELF Lubricants, North America
Eller-Montan-Comp-Duisburg/D
ESSO Lubricants Europe, Brussel/B
ESSO Imperial Oil NA
ESSO Imperial Oil NA
Fina Europe, SA Brussel/B
Fina Europe, SA Brussel/B
Fuchs Dea Schmierstoffe, Mannheim/D
Fuchs Dea Schmierstoffe, Mannheim/D
Fuchs Dea Schmierstoffe, Mannheim/D
Furukawa Co LTD, Japan
Genol GMBH, Wiena/A
Ginouves Georges SA, LA Farieda/F
HAFA, Paris/F
Igol France, Paris/F
Indian Oil Corp, Faridabad/Ind

TRADE NAME

Addinol Getriebeol 85W90 LS
Agip Rotra, MP/S
Aral Degol 3216
Avia Hypoid 90 LS
Baywa Getriebeol Hypoid LS 90
Hypoid-Getriebeol LS
Frontal Getriebeol LS
Energear Limslip 90
Motorex Gear Oil LS
Calpam Gear Oil LS 90
Castrol Hypoy LS
Castrol LSX
Citgo Premium LS 80W-90
Citgo Synthetic 75W-90
Antar BLS
HRD EP GL
Tranself Typ BLS
Gear Elf BIS90
Elimo-Hypoid LS
Esso Getriebeol LSA 85W90
Esso GX LS 80W-90
Esso Extra LS 75W-90
Fina Pontonic LS
Fina Dynatrans LS
Dealear LS
Titan Gear LS90
Dealear AWB
Kyoseki FK Axle 80W90
Genol Hypolube LS 90
York 798 LS
Hypoid PA
Igol Hypoid BPA
Servp Gear Super LS 90

MANUFACTURER

Italiana Petroli, Genova A/I
Kompressol-OEL, Koin/D
Leprince + Siveke GMBH, Herford/D
Liqui Moly GMBH, ULM/D
Meguin GMBH, Saariouis/D
MIN.OL-Raffin Dollbergen, Uetza/D
Mobil Oil, Wedel/D
Mobil USA
Mol Hungarian Oil, Komarom/H
Motul AS, Valres Sur Marne/F
Nova Stilmoll SPA, Modena/I
Nova Stilmoll SPA, Modena/I
Oest G. Min.Ol-Werk, Freudenstadt/D
OMV AG. Schwechat/A
Orfy International, Vieux-Thann/F
Pakelo Motor Oil, San Bonifacio/I
Panolin AG, Madetswil/CH
Pennzoil NA
Quaker State NA
Raiffeisen HG Nord AG, Hannover/D
Repsol Distribucion SA, Madrid/E
SAEL Madrid/E
Schmierstoffraffinerie Saizbergen/D
Shell Aseol AG, Bern/CH
Shell International London/GB
SK Corporation, Eeoul/Korea
Texaco Belgium N.V. Brussels/B
Texaco USA
Total Raffinage Distr. Paris/F
Turbotank Bosche+Bodeker, Bremen/D
Unil Deutschland GMBH, Bremen/D
Unil Opal, Rueil Maimaison/F
Veedol International, Swindon/GB
Yacco SA, St Pierre-LES-Elbeuf/F

TRADE NAME

IP Pontiax LS
Kompressol-Hypoid EW LS
Leprinxol LS
LM Hypoidgetriebeol GL-5 LS
Megol Hypoidgetriebeol GL-5 LS
Pennasol Sperrdiff-Getr.OL
Mobilube LS
Mobilube HD 80W-90 LS
Carrier Hykomol LS
Motul 90 PA
Gearing Wonder LS 85W90
Gear G3 Lube Special Line 90
Getriebeol Hypoid LS 90
OMV Gear Oil LS
Orfy Tucana LS
Pakelo Universal Gear EP/LS
Panolin Super Duty LS
4096 80W-90LS
HP 80W-90
HG Getriebeol LS 90
S EP Autoblocante
Gulf LS Rear Axle Oil
Wintershall Wiolin RSH
Aseol Topress LS
Shell Getriebeol 90 LS
SK G-LS 80W/90 Gear Oil
Geartex LS
Mutliger EP 80W-90
Total Transmission DA
Turbo Getriebeol LS
Unil Gear AB EP
Unil Opal Gear AB-EP
Veedol Multigear L
Yahypo BN 90

NOTES: 1) The above list of oils is not meant to be an all inclusive list of acceptable oils for use in Dana products. **2)** It is the end users responsibility to select the best grades of oils available in the local area that provide proper viscosity and limited slip friction additives for long product life and noise free operation. **3)** Intermixing of GL5 oils with UTTO GL4 oils is not recommended as they are not compatible.





BEARING HEATING AND FREEZING GUIDELINES

Bearings often must be cooled or heated to aid in assembly or removal. Since temperature extremes can cause permanent bearing metallurgical damage, it is important to take proper precautions and use correct methods when heating and cooling bearings.

Cups that are to be assembled in hubs or housings with a press fit may be shrunk in a deep freeze unit. Standard class bearings should not be cooled below -65° F (-54° C). In addition to cooling the bearing cup, in some instances it may be necessary to heat the housing.



To control temperature, is best to use a thermostat along with a freezer unit or a properly calibrated thermometer. If a suitable freezer or thermometer is not available, your Timken service representative can suggest liquid combinations that freeze the bearing cup at the optimal temperatures. Regardless of the method, check the cup's final seating against the housing shoulder with feeler gauges.

Take extreme care that standard product bearings are never heated above 149° C [300° F]. If bearings are heated above this temperature, their metallurgical structure may soften, rendering them unsuitable for use.

There are a number of recommended methods for heating bearings. Electric ovens or electrically heated oil baths may be used, but only when accompanied by proper thermostatic control. If you use a hot plate to heat the oil, never rest bearings directly on the bottom of the pan. Instead, protect bearings from the heat source with a simple wire screen holder or similar device.

Use heat-resistant gloves to handle heated cones. Hold the hot cone solid against the cold shoulder on the shaft until the cone grabs on to the shaft. The hot cone will pull away from the cold shoulder unless it is held in position. Use .002 [.05 mm] feeler gages to make sure the cone is fully seated against the shoulder after the parts are cooled. Many loose bearing settings (excessive end play) are caused by an unseated cone working back against the shoulder in service.

LEFT HAND SPIRAL SPIRAL BEVEL AND HYPOID TOOTH BEARING CHART



ALL CONTACT BEARINGS SHOWN BELOW ARE ON **LEFT HAND SPIRAL** RING GEAR - THE DRIVE IS ON THE CONVEX SIDE OF THE TOOTH.




FIG.1
TYPICAL PREFERRED BEARING ON BOTH SIDES OF TOOTH
WHILE UNDER A LIGHT LOAD





FIG.2
TOE BEARING ON BOTH SIDES OF TOOTH - GEAR SET NOISY. TO MOVE
BEARING TOWARD HEEL INCREASE BACKLASH WITHIN LIMITS BY
MOVING GEAR AWAY FROM PINION.





FIG.3
HEEL BEARING ON BOTH SIDES OF TOOTH - GEAR SET NOISY AND
COULD RESULT IN EARLY GEAR FAILURE. TO MOVE BEARING TOWARD
TOE DECREASE BACKLASH WITHIN LIMITS BY MOVING GEAR TOWARD PINION





FIG.4
LOW BEARING ON GEAR AND HIGH BEARING ON PINION. CORRECT
BY PULLING PINION AWAY FROM GEAR (INCREASE MOUNTING DISTANCE)








FIG.5
HIGH BEARING ON GEAR AND LOW BEARING ON PINION. CORRECT
BY MOVING PINION TOWARD GEAR (DECREASE MOUNTING DISTANCE)



BACKLASH

BACKLASH SHOULD BE MEASURED WITH A DIAL INDICATOR RIGIDLY MOUNTED WITH THE STEM PERPENDICULAR TO THE TOOTH SURFACE AT THE EXTREME HEEL. SEE SHEET NO. 2 FOR BACKLASH VALUES.

RIGHT HAND SPIRAL SPIRAL BEVEL AND HYPOID TOOTH BEARING CHART



ALL CONTACT BEARINGS SHOWN BELOW ARE ON **RIGHT HAND SPIRAL** RING GEAR - THE DRIVE IS ON THE CONVEX SIDE OF THE TOOTH.




FIG.1
TYPICAL PREFERRED BEARING ON BOTH SIDES OF TOOTH WHILE UNDER A LIGHT LOAD





FIG.2
TOE BEARING ON BOTH SIDES OF TOOTH - GEAR SET NOISY. TO MOVE BEARING TOWARD HEEL INCREASE BACKLASH WITHIN LIMITS BY MOVING GEAR AWAY FROM PINION.





FIG.3
HEEL BEARING ON BOTH SIDES OF TOOTH - GEAR SET NOISY AND COULD RESULT IN EARLY GEAR FAILURE. TO MOVE BEARING TOWARD TOE DECREASE BACKLASH WITHIN LIMITS BY MOVING GEAR TOWARD PINION




FIG.4
LOW BEARING ON GEAR AND HIGH BEARING ON PINION. CORRECT BY PULLING PINION AWAY FROM GEAR (INCREASE MOUNTING DISTANCE)






FIG.5
HIGH BEARING ON GEAR AND LOW BEARING ON PINION. CORRECT BY MOVING PINION TOWARD GEAR (DECREASE MOUNTING DISTANCE)



BACKLASH

BACKLASH SHOULD BE MEASURED WITH A DIAL INDICATOR RIGIDLY MOUNTED WITH THE STEM PERPENDICULAR TO THE TOOTH SURFACE AT THE EXTREME HEEL. SEE SHEET NO. 2 FOR BACKLASH VALUES.



CLEANING AND INSPECTION

CLEANING

Clean all parts thoroughly using solvent type cleaning fluid. It is recommended that parts be immersed in cleaning fluid and agitated slowly until parts are thoroughly cleaned of all old lubricants and foreign materials.

CAUTION: Care should be exercised to avoid skin rashes, fire hazards and inhalation of vapors when using solvent type cleaners.

BEARINGS

Remove bearings from cleaning fluid and strike larger side of cone flat against a block of wood to dislodge solidified particles of lubricant. Immerse again in cleaning fluid to flush out particles. Repeat above operation until bearings are thoroughly clean. Dry bearings using moisture free compressed air. Be careful to direct air stream across bearings to avoid spinning. Bearings may be rotated slowly by hand to facilitate the drying process.

TRUMPET ARMS, COVERS AND CAPS

Clean interior and exterior of trumpet arms, bearing caps, etc., thoroughly. Cast parts may be cleaned in hot solution tanks with mild alkali solutions, providing these parts do not have ground or polished surfaces. Parts should remain in solution long enough to be thoroughly cleaned and heated. This will aid the evaporation of the cleaning solution and rinse water. Parts cleaned in solution tanks must be thoroughly rinsed with clean water to remove all traces of alkali. Cast parts may also be cleaned with steam cleaner.

CAUTION: Care should be exercised to avoid skin rashes and inhalation of vapors when using alkali cleaners. Thoroughly dry all parts cleaned immediately by using moisture-free compressed air or soft lintless absorbent wiping rags free of abrasive materials such as metal filings, contaminated oil or lapping compound.

INSPECTION

The importance of careful and thorough inspection of all parts cannot be overstressed. Replacement of all parts showing indication of wear or stress will eliminate costly and avoidable failures at a later date.

BEARINGS

Carefully inspect all rollers, cages and cups for wear, chipping or nicks to determine fitness of bearings for further use. Do not replace a bearing without replacing the mating cup or cone at the same time. After inspection, dip bearings in clean light oil and wrap in clean lint free cloth or paper to protect them until installed.

OIL SEALS, GASKETS AND RETAINING RINGS

Replacement of spring loaded oil seals, gaskets, and snap rings is more economical when unit is disassembled than to risk premature overhaul to replace these parts at a future time. Loss of lubricant through a worn seal may result in failure of other more expensive parts of the assembly. Sealing member should be handled carefully, particularly when being installed. Cutting, scratching or curling under lip of seal seriously impairs its efficiency. At reassembly, lubricate lips of oil seals with Multipurpose Lithium grease "Grade 2".



CLEANING AND INSPECTION - CONT.

GEARS AND SHAFTS

If Magna-Flux or a dye penetrant process is available use process to check parts. Examine teeth and the ground/polished surfaces of all gears and shafts carefully for wear, pitting, chipping, nicks, cracks, or scoring. If gear teeth are cracked or show spots where case hardening is worn through, replace with new gear. Small nicks may be removed with suitable hone stone. Inspect shafts to make certain they are not sprung, bent or have twisted splines.

TRUMPET ARMS, COVERS AND CAPS

Inspect trumpet arms and covers to be certain they are thoroughly cleaned and that mating surfaces, bearing bores, etc. are free from nicks or burrs. Check all parts carefully for evidence of cracks or conditions which can cause oil leaks or failures.



FASTENER TORQUE CHART

STANDARD FASTENERS						
Lubricated and Plated Bolts, CapScrews, and Studs						
	Grade 5			Grade 8		
	3 Radial Dashes On Bolt Head			6 Radial Dashes On Bolt Head		
Size	LBF/FT	[Nm]		LBF/FT	[Nm]	
1/4-20	10	14		11	15	
1/4-28	11	15		13	18	
5/16-18	16	22		30	41	
5/16-24	20	27		32	43	
3/8-16	25	34		36	49	
3/8-24	29	39		41	56	
7/16-14	41	56		57	77	
7/16-20	45	61		64	87	
1/2-13	63	85		88	119	
1/2-20	70	95		99	134	
9/16-12	90	122		127	172	
9/16-18	100	136		141	191	
5/8-11	124	168		175	237	
5/8-18	141	191		198	268	
3/4-10	220	298		310	420	
3/4-16	245	332		347	470	
METRIC FASTENERS						
Lubricated and Plated Bolts, CapScrews, and Studs						
	Class 8.8		Class 10.9		Class 12.9	
	8.8 on Bolt Head		10.9 on Bolt Head		12.9 on Bolt Head	
Size	LBF/FT	[Nm]	LBF/FT	[Nm]	LBF/FT	[Nm]
M4	2.2	3	3.2	4.4	7.4	10
M5	4.4	5.9	6.4	8.7	7.4	10
M6	7.4	10	11	15	13	18
M8	18	25	26	36	19	26
M10	36	49	51	72	50	68
M12	63	85	92	125	76	103
M14	100	135	147	200	142	193
M16	155	210	229	310	222	301
M18	221	300	317	430	369	500
M20	313	425	450	610	432	586
M22	428	580	605	820	516	700
M24	538	730	774	1050	748	1014

PIPE PLUGS		
Size (NPTF)	LBF/FT	[Nm]
1/16-27	7	9
1/8-27	10	14
1/4-18	20	27
3/8-18	30	41
1/2-14	35	47
3/4-14	45	61
1-11 1/2	55	75
1 1/4-11 1/2	65	88

Trumpet Arm Removal



Figure 1
Remove (2) socket head screws
and washers 180° apart from trumpet arm.



Figure 2
Install (2) alignment pins in place of
socket head screws and washers.



Figure 3
With trumpet arm securely supported, remove
remainder of socket head screws and washers.



Figure 4
Carefully separate trumpet arm from differential carrier.
NOTE: Insure axle is secured to prevent injury when trumpet
arm is removed.

Trumpet Arm, Brake and Planetary Disassembly




Figure 5
Remove reaction plate.



Figure 6
Remove friction plate.
NOTE: Measure friction disc for wear.
The minimum thickness is 4.57 mm [.180"].



Figure 7
Remove sun gear. **NOTE:** If axle does not have brakes proceed to **figure 11**.



Figure 10
Remove abutment plate.



Figure 8
Remove (4) brake piston return springs.



Figure 11
Remove internal ring gear snap ring.
NOTE: Does not apply to axle with brakes.



Figure 9
Remove brake abutment plate snap ring.



Figure 12
Remove (12) dowel pins.
NOTE: A magnet is helpful in this procedure.



Figure 13

Remove internal ring gear.

NOTE: If not replacing planet gear and bearing assemblies skip **figures 14, 15 & 17** and proceed to **figure 16 & 18** to remove planetary and clamp plate as a complete assembly.



Figure 16

Remove (4) socket head screws.



Figure 14

Remove (4) planet gear and bearing snap rings.



Figure 17

Remove clamp plate and shims.



Figure 15

Using appropriate puller remove (4) planet gear and bearing assemblies.



Figure 18

Remove planet carrier.



Figure 19

Install a pusher tool as shown and press or use a soft bar and drive axle shaft out of the inner wheel bearing cone.

NOTE: Reference pressing tool in **figure 20**.

IMPORTANT: Support flange end of axle shaft as shown in **figure 21** during this procedure.



Figure 20

Typical pusher tool which may be fabricated to remove axle shaft.



Figure 21

Remove axle shaft. **NOTE:** Bar inserted in bottom stud hole, as shown, will assist in positioning axle shaft during disassembly and reassembly procedures.



Figure 22

Remove inner wheel bearing cone.



Figure 23

Remove face seal. **NOTE:** If reusing seals keep original mated steel sealing rings as a set. Reference face seal installation instructions on *page 19*.



Figure 24

Cut wheel bearing cone cage and remove bearing rollers.

Using a die grinder, as shown, carefully cut the inner race of the wheel bearing cone.

IMPORTANT: Be careful to not damage axle shaft.



Figure 25

Using a screwdriver expand inner race and remove.



Figure 28

Remove outer wheel bearing cup.



Figure 26

Remove face seal from trumpet arm.



Figure 29

Drive inner wheel bearing cup from trumpet arm and remove. Reference **figure 27**. Repeat process for opposite trumpet arm.



Figure 27

Drive outer wheel bearing cup from trumpet arm.



Figure 30

Remove seal ring from differential carrier housing.
Remove (2) alignment pins.



Figure 31

Remove brake piston.

NOTE: Procedures in **figures 31&32** do not apply to axles without brakes.



Figure 32

Remove (2) brake piston seals and (2) backup rings.
Repeat process in **figures 30-32** for opposite side.

Hydraloc Differential Disassembly



Figure 33



Figure 36
Loosen pinion nut.



Figure 34
Position unit on bench, support with blocks as shown.



Figure 37
Remove pinion nut.

Drive Flange V-Ring and Wear Sleeve Removal



Figure 35
Heat pinion nut to release thread locking compound.



Figure 38
Remove pinion spacer, seal ring and o-ring.



Figure 39
Remove flange.



Figure 42
Grind the cutting edge of a chisel to a radius as shown.



Figure 40
Remove v-ring seal from flange.



Figure 43
Use rounded tip chisel to expand and remove wear sleeve by striking evenly across the width of the sleeve in the three marked locations. **IMPORTANT:** Do not cut through wear sleeve as damage to the flange will occur.



Figure 41
Mark flange wear sleeve in three equally spaced locations as shown across the full width of sleeve.

Pinion Seal Retainer Cartridge and Seal Removal



Figure 44
Install (2) M8 screws and flat washers in puller holes.



Figure 45
Remove seal retainer cartridge.



Figure 48
Remove o-ring.



Figure 46
Remove pinion seal from cartridge.



Figure 49
Remove grease fitting.

Differential Retainer and Adjuster Removal



Figure 47
Remove grease seal and thrust washer.



Figure 50
Remove (2) differential adjusting nut
cap screws and lock.



Figure 51

Remove adjusting nut lock socket head screw.



Figure 54

Remove (2) seal retainer seal rings.



Figure 52

Remove (4) seal retainer cap screws.



Figure 55

Remove seal retainer inner oil seal.



Figure 53

Remove seal retainer.



Figure 56

Remove seal retainer outer oil seal.



Figure 57
Remove (4) differential retainer cap screws.



Figure 60
Install (2) M8 eye bolts.



Figure 58
Loosen differential adjusting nut.
Reference tool drawing on *page 92*.



Figure 61
Install (2) chain clevises, attach hoist.



Figure 59
Remove differential adjusting nut.



Figure 62
Remove differential retainer.

Differential Assembly Removal



Figure 63
Remove (2) piston rings.



Figure 64
Remove (2) ring gear mounting cap screws
and washers 180° from each other.



Figure 65
Install (2) M16 eye bolts.



Figure 66
Attach hoist and remove differential assembly
and ring gear.

Ring Gear Removal



Figure 67
Remove (14) ring gear cap screws and washers.



Figure 68
Position wood blocks or equivalent under ring gear and
tap with mallet to remove from differential body.
Reference **figure 69**.



Figure 69

Wood blocks or equivalent placed under ring gear to prevent ring gear damage.



Figure 72

Remove case flanged half.

Differential Body Disassembly




Figure 70

Mark case as shown in (2) places for proper alignment during reassembly.



Figure 73

Remove side gear thrust washer.



Figure 71

Remove (2) cap screws.



Figure 74

Remove reaction and friction discs.



Figure 75
Remove side gear.



Figure 78
Remove side gear thrust washer.



Figure 76
Remove (12) socket head screws and washers.



Figure 79
Remove side gear.



Figure 77
Remove differential cap.



Figure 80
Remove spider with pinion gears and thrust washers.



Figure 81
Remove (4) pinion gear thrust washers.



Figure 84
Apply heat and remove wear sleeve.



Figure 82
Remove (4) pinion gears.



Figure 85
Apply heat and remove differential bearing cone.



Figure 83
Apply heat and remove differential bearing cone.
Reference bearing heating and freezing guidelines on page 23.

Piston Removal



Figure 86
Position differential flange half on bench as shown. Use compressed air to push piston out of bore.

Pinion Removal



Figure 87
Remove piston.



Figure 90
Install pinion nut to protect threads and tap pinion through outer bearing cone.



Figure 88
Remove outer piston seal and back up ring.



Figure 91
Remove pinion assembly. Remove pinion nut.



Figure 89
Remove inner piston seal and back up ring.



Figure 92
Remove pinion inner bearing cone.



Figure 93
Remove pinion outer bearing cone.



Figure 96
Remove pinion outer bearing cup.



Figure 94
Remove differential bearing adjusting nut and cup.



Figure 97
Remove bleeder screw and seat.



Figure 95
Remove pinion inner bearing cup and shim.




Figure 98
Remove plug and o-ring.



Figure 99
Remove plug and o-ring.

Hydraloc Differential Reassembly



Figure 100
Apply thin, continuous coat of Loctite 620 or equivalent to wear sleeve mounting surface.



Figure 101
Apply thin, continuous coat of Loctite 620 or equivalent to inside diameter of wear sleeve.



Figure 102
Install wear sleeve on flange half.
NOTE: End of sleeve should be flush with end of journal.
Reference tool drawing on *page 93*.



Figure 103

Use compressed air to blow excess sealant from oil passage.



Figure 106

Lubricate spider with axle lubricant and install (4) pinion gears.



Figure 104

Clean cured thread locking compound from tapped holes with M14x2 tap. Remove remaining residue from holes.



Figure 107

Lubricate and install (4) thrust washers.



Figure 105

Heat and install differential bearing cone on cap half. Reference bearing heating and freezing guidelines on *page 23*.



Figure 108

Install assembly in clutch housing.



Figure 109
Install side gear.



Figure 112
Lubricate thrust washer.



Figure 110
Lubricate side gear.



Figure 113
Install differential cap.
NOTE: Align identification marks.



Figure 111
Install thrust washer.



Figure 114
Install (12) socket head screws and washers.



Figure 115
Tighten screws in a star pattern to 183-202 Nm [135-149 LBF/FT].



Figure 118
Lubricate both sides of friction disc and install. Alternately install remaining reaction and friction discs.
NOTE: Align lube grooves with each other.



Figure 116
Install side gear.



Figure 119
Lubricate side gear.



Figure 117
Lubricate both sides of reaction disc and install.



Figure 120
Install thrust washer.



Figure 121

Install piston outer seal back up ring.



Figure 124

Install piston inner seal ring.

NOTE: Back up ring must be installed prior to seal ring.



Figure 122

Install piston outer seal ring.

NOTE: Back up ring must be installed prior to seal ring.



Figure 125

Lubricate piston seals and bore.
Position piston in bore.



Figure 123

Install piston inner seal back up ring.



Figure 126

Carefully tap piston into bore evenly with mallet.

Ring Gear Installation



Figure 127

Install differential flange half.

NOTE: Align identification marks as shown.



Figure 130

Clean foreign material and/or cured thread locking compound from holes with M16x2 tap. Remove remaining residue from holes.



Figure 128

Apply Loctite 262 or equivalent to (2) cap screws and install.



Figure 131

Use hone stone or file to remove nicks or burrs from mounting face.

NOTE: Be sure to remove all abrasive residue.



Figure 129

Tighten (2) cap screws to 24-27 Nm [18-20 LBF/FT].



Figure 132

Use hone stone or file to remove nicks or burrs from mounting face.

NOTE: Be sure to remove all abrasive residue.



Figure 133

Heat ring gear to 93-100°C [200-212°F] and install.

Caution: Use gloves to avoid injury.



Figure 134

Temporarily install (2) ring gear mounting screws 180° apart and tighten to 135 Nm [100 LBF/FT].

Allow assembly to cool before installing additional screws.

IMPORTANT: Using a .05 mm [.002"] feeler gauge check several locations around ring gear to be sure there is no gap between the ring gear and differential body mounting faces.

NOTE: Assembly is shown with ring gear down for clarity.

This procedure should be performed with assembly in same position as shown in **figure 133**.



Figure 135

Heat and install differential bearing cone. Reference bearing heating and freezing guidelines on *page 23*.

Pinion Installation and Adjustment



Figure 136

Locate ring gear mounting distance dimension located in this area and record.



Figure 137

Number as it appears in **figure 136**.



Figure 138

Locate ring gear mounting distance dimension on ring gear and record.



Figure 139

Measure height of pinion inner bearing cup and cone and record. Calculate ring and pinion mounting distance shim as follows:

Example

Number from housing	232.560 mm [9.1559"]
Number from ring gear	- 186.106 mm [7.3270"]
Bearing height	- 45.974 mm [1.8100"]
	- .127 mm [.0050"]
Shim thickness required	.353 mm [.0139"]



Figure 141

Install pinion outer bearing cup.



Figure 142

Install mounting distance shim as determined in **figure 139**.



Figure 140

Heat and install pinion inner bearing cone. Reference bearing heating and freezing guidelines on [page 24](#).




Figure 143

Freeze and install pinion inner bearing cup. Reference bearing heating and freezing guidelines on [page 24](#).



Figure 144

Check for proper seating of pinion inner and outer bearing cups. Reference bearing heating and freezing guidelines on *page 23*.



Figure 147

Lubricate pinion outer bearing cone.



Figure 145

Lubricate pinion inner bearing cone.



Figure 148

Heat and install pinion outer bearing cone.



Figure 146

Install pinion.



Figure 149

Install flange.



Figure 150
Install pinion spacer.

Pinion rolling resistance recorded in **figure 152** should be 1.13-3.95 Nm [10-35 LBF/IN].

If within specification remove nut, spacer and flange.

If not within specification repeat steps in **figures 150-152** making appropriate spacer substitution.

If rolling resistance is too low reduce spacer thickness. If rolling resistance is too high increase spacer thickness.

Figure 153



Figure 151
Install pinion nut and tighten to 1261-1396 Nm [930-1030 LBF/FT].

Pinion Seal Installation



Figure 154
Apply thin continuous coat of Loctite 620 or equivalent to pinion seal bore.



Figure 152
Check pinion bearing rolling resistance and record.



Figure 155
Using appropriate driver, install pinion seal. Reference tool drawing on page 89.



Figure 156

Apply thin continuous coat of Loctite 620 or equivalent to grease seal bore.



Figure 159

Apply Loctite 620 or equivalent to threads and install grease fitting.



Figure 157

Using appropriate driver install grease seal and thrust washer. Reference tool drawing on *page 88*.




Figure 160

Apply light coat of grease to sealing ring sealing surface in carrier bore.



Figure 158

Install o-ring. Apply thin continuous coat of Loctite 620 or equivalent to pilot dia. of retainer as indicated.



Figure 161

Apply grease to thrust washer face and seal lips.



Figure 162
Position seal retainer in bore.



Figure 163
Index retainer so eye brows align.



Figure 164
Carefully tap retainer with a soft mallet evenly around diameter to install.

Wear Sleeve Installation



Figure 165
Apply continuous coat of Loctite 620 or equivalent to wear sleeve I.D.



Figure 166
Using appropriate driver install wear sleeve.
Reference tool drawing on page 94.

Pinion Flange Installation



Figure 167
Install v-ring seal.



Figure 168
Install input flange.



Figure 171
Apply Loctite 262 or equivalent to pinion nut threads.



Figure 169
Install o-ring and o-ring spacer.



Figure 172
Tighten pinion nut to 1261-1396 Nm [930-1030 LBF/FT].
Reference **Figure 163** for fitting location and apply grease to input seals until it comes out from around the v-ring lip.
NOTE: Seals should be greased at every normal servicing interval. Machines in conditions where the axle routinely becomes submerged should be serviced more often.



Figure 170
Install pinion spacer identified in **figure 153**.

Carrier Housing Assembly



Figure 173
Install differential bearing cup.



Figure 174

Install differential bearing adjusting nut.



Figure 177

Lock or hold pinion shaft from turning.

Differential Assembly Installation



Figure 175

Paint 5 to 6 ring gear teeth with contact checking compound.



Figure 178

Remove (1) of (2) ring gear cap screws and mark head of remaining screw for identification purposes.



Figure 176

Install differential assembly in housing.



Figure 179

Apply Loctite 262 or equivalent to (15) ring gear mounting cap screws and install with washers. Run down but do not tighten. **IMPORTANT: Perform the procedures shown in figures 179-181 in a timely manner before the Loctite begins to cure.**



Figure 180

Remove marked cap screw, apply Loctite 262 or equivalent and install with washer.



Figure 181

Tighten (16) ring gear mounting cap screws in a star pattern to 286-316 Nm [211-233 LBF/FT]. Using a brass bar or equivalent sharply shock assembly in several locations around the bolt circle. Immediately retighten all cap screws in a star pattern to 286-316 Nm [211-233 LBF/FT].



Figure 182

Release pinion shaft.

Differential Retainer Installation



Figure 183

Install differential bearing cup.



Figure 184

Install differential retainer o-ring and lubricate with grease.



Figure 185

Install differential bearing adjusting nut.



Figure 186

Lubricate differential bearing cone with axle lubricant.



Figure 187

Install (2) piston rings. Coat rings with grease and center in grooves.



Figure 188

Install (2) alignment pins located 180° apart.



Figure 189

Install differential retainer.



Figure 190

Install (4) retainer cap screws and tighten to 24-27 Nm [18-20 LBF/FT].

Backlash and Contact Pattern Setup and Adjustment



Figure 191

Tighten differential adjusting nuts to a minimum of 41 Nm [30 LBF/FT]. Rotate pinion back and forth while performing this step to assure that detectable backlash exists and ring gear is not being forced into pinion gear. Reference tool drawing on page 92.



Figure 192

Set up magnetic base dial indicator as shown to measure ring and pinion backlash.

With ring gear being held stationary, rock the pinion flange back and forth gently while watching the reading on dial indicator.

Backlash specifications are as follows:

37R 4.556 ratio with 6C-TP Flange .46-.74 mm [.018-.029"]

37R 4.556 ratio with 7C-TP Flange .48-.79 mm [.019-.031"]

37R 5.125 ratio with 6C-TP Flange .56-.89 mm [.022-.035"]

37R 5.125 ratio with 7C-TP Flange .58-.94 mm [.023-.037"]

If the readings are out of specification, move the differential adjusting nuts inward or outward together. **IMPORTANT:** Recheck differential bearing preload after the proper backlash reading is achieved. **Refer to figure 191.**

Figure 193



Figure 194

Install differential adjusting nut lock.

IMPORTANT: Advance adjusting nut if necessary to line up mounting holes. **Do Not** loosen/back off nut.



Figure 195

Apply Loctite 262 or equivalent to (2) nut lock cap screws and install. Tighten to 24-27 Nm [18-20 LBF/FT].



Figure 196

Install stub shaft. **NOTE:** The sun shaft and a socket can be used to perform this procedure.



Figure 198

Inspect tooth contact pattern on ring gear. Compare to tooth bearing charts on *pages 25 & 26* and make adjustments if necessary as indicated.

Hydraloc Seal Retainer Assembly and Installation



Figure 197

Step #1

Hold pinion and rotate side gear five turns in each direction. Differential clutch must turn freely with a maximum torque of 34 Nm [25 LBF/FT].

Step #2

Hold side gear and rotate pinion in both directions to make several passes through the gear contact checking compound on the ring gear.



Figure 199

Apply continuous coat of Loctite 620 or equivalent to outside diameter of inner Hydraloc seal.



Figure 200

Using appropriate driver install inner Hydraloc seal.

NOTE: Seal is installed with sealing lip down or towards center of seal retainer. Reference tool drawing on *page 90*.



Figure 201

Apply continuous coat of Loctite 620 or equivalent to outside diameter of outer Hydraloc seal.



Figure 204

Install seal retainer plug.

NOTE: Plug end to be flush with mating surface.



Figure 202

Using appropriate driver install outer Hydraloc seal.

NOTE: Seal is installed with sealing lip down or towards center of seal retainer. Reference tool drawing on page 91.



Figure 205

Coat with grease, to hold in position, and install (2) seal rings in seal retainer.



Figure 203

Apply Loctite 262 or equivalent to seal retainer plug.



Figure 206

Insert seal retainer installation tool. Reference tool drawing on page 95.



Figure 207

Coat inner and outer Hydraloc seal lips with grease.



Figure 210

Tighten seal retainer cap screws to
24-27 Nm [18-20 LBF/FT].



Figure 208

Carefully install seal retainer.

Note: Holes on seal retainer must be aligned with holes
on the pressure and tank ports on the differential
retainer.



Figure 211

Apply Loctite 262 or equivalent to differential
adjusting nut lock socket head screw.
Install socket head screw in one of the two holes that
allow it to clear the lugs on the adjusting nut.



Figure 209

Install (4) seal retainer cap screws.



Figure 212

Tighten adjusting nut socket head lock screw to
48-50 Nm [35-37 LBF/FT].

Hydraloc Air Leakage Test



Figure 213

Air pressure test per procedure on *page 18*.

Hydraloc Hydraulic Leakage Test



Figure 214

Hydraulic pressure test per procedure on *page 18*.

Hydraloc Functional Test



Figure 215

Functional test per procedure on *page 18*.



Figure 216

Install (2) bleeder screws and seats.
Tighten to 9-14 Nm [7-10 LBF/FT].



Figure 217

Install (2) brake supply port plugs and (1) drain and oil level plug. Tighten to 41-47 Nm [30-35 LBF/FT].



Figure 218

Install (2) Hydraloc port plugs.
Tighten to 41-47 Nm [30-35 LBF/FT].

Brake Piston Reassembly



Figure 219

Lubricate, stretch and install (1) outer piston seal. Lubricate, stretch and install (1) outer piston backup ring on top of piston seal. For proper ring placement reference **Figure 223**.



Figure 221

Install piston.



Figure 220

Lubricate, stretch and install (1) inner piston seal. Lubricate, stretch and install (1) inner piston backup ring on bottom of piston seal.



Figure 222

Fabricate and install plates and spacers as shown. Evenly tighten bolts to push piston into bore. Repeat procedure on opposite side.




Figure 223

Brake Air Test



Figure 224

Install brake assembly retaining plates.




Figure 225

Tighten screws.

NOTE: Leave 3.81 mm (.149") clearance between retaining plates and brake to allow movement of brake.

IMPORTANT: Do not hydraulic test.



Figure 226

Remove bleeder and seat. Install air tester as shown. This checking device is comprised of minimum 690 kPa [30 psi] air gauge, air shut off valve and regulator.

Apply 83 kPa (12 psi) for 20 seconds.

Allow another 20 seconds for air stabilization period.

Allow another 10 seconds for decay period.

A maximum of 8 kPa decay allowed. If decay exceeds 8 Pa [.001 psi] repeat above steps.

If decay exceeds 8 Pa [.001 psi] after 3 trials, disassemble and inspect for cause.

Correct and retest.

Repeat test on opposite side.

Note: Alternate decay/period is .69kPa [.1 PSI] per 5 minutes.



Figure 227

Install bleeder seat flat side down, Install bleeder and tighten to 9-14 Nm [7-10 LBF/FT].

Brake Piston Positioning "Clocking"



Figure 228

Prior to installing the trumpet arm it is **"Imperative"** that the brake piston ears be in the correct position. If the piston ears are out of position during reassembly they may break or the piston return springs will not make contact, possibly causing brake drag. Temporarily install the abutment plate on the piston, engaging the cutouts in the abutment plate with the ears on the piston as shown.



Figure 229

Using the dowel pin hole as reference install (2) alignment pins as shown in the 4th and 9th holes from the dowel pin hole.




Figure 230

Measure the distance from alignment pins to eye brows in abutment plate. Turn abutment plate to position the eye brows an equal distance from each pin. Carefully remove abutment plate without disturbing piston position. Perform this procedure on both brake pistons.

Trumpet Arm Reassembly



Figure 231

Freeze inner wheel bearing cup and install. Reference bearing heating and freezing guidelines on *page 23*.



Figure 234

Freeze outer wheel bearing cup and install.



Figure 232

Using a soft bar tap around bearing cup to assure it is properly seated in bore.



Figure 235

Using a soft bar tap around bearing cup to assure it is properly seated in bore.



Figure 233

Using a feeler gauge check between cup and housing in several places to be sure bearing cup is properly seated. Reference bearing heating and freezing guidelines on *page 23*.



Figure 236

Using a feeler gauge check between cup and housing in several places to be sure bearing cup is properly seated.



Figure 237

Heat outer wheel bearing cone. Reference bearing heating and freezing guidelines on *page 23*.



Figure 240

Using a feeler gauge check between cone and shaft shoulder in several places to be sure bearing cup is properly seated.



Figure 238

Install outer wheel bearing cone.

Face Seal Installation



Figure 241

Clean seal bore in axle shaft with solvent. Reference face seal installation instructions on *page 19*.



Figure 239

Tap inner race of bearing to assure it is properly seated on shaft. **NOTE:** The old bearing race, as shown, works well for this procedure and minimizes the risk of damaging the bearing.



Figure 242

Clean metal ring sealing surface with a lint free cloth.



Figure 243
Install seal in installation tool.



Figure 246
Check that seal is properly seated.
Wipe seal with lint free cloth and
apply light coat of oil to steel sealing surface.



Figure 244
Wet rubber toric ring with isopropyl alcohol or other
approved evaporative solvent. Reference face seal
installation instructions on *page 19*.



Figure 247
Clean seal bore in trumpet arm with solvent.



Figure 245
Install seal.



Figure 248
Install seal in installation tool.



Figure 249

Wet rubber toric ring with isopropyl alcohol or other approved evaporative solvent. Reference face seal installation instructions on *page 19*.



Figure 250

Install seal.



Figure 251

Check that seal is properly seated. Wipe seal with lint free cloth and apply light coat of oil to steel sealing surface.



Figure 252

Install axle shaft in trumpet arm. **NOTE:** Be careful to not damage the bearing cups or seals.



Figure 253

Heat inner bearing cone and install on axle shaft. **NOTE:** An assistant is needed for this procedure to hold the axle shaft centered in the bearing cup from the flange end. Reference *figure 252*.



Figure 254

Using a soft bar tap bearing fully on the axle shaft. **NOTE:** An assistant is needed for this procedure to hold the axle shaft in position.



Figure 255

Install planet carrier.

IMPORTANT: Position planet carrier on the axle shaft splines so the threaded holes in shaft are equally spaced between the planet gear bearing bosses as shown in **figure 258**. This will allow access to the socket head screws between the gears when removing or installing a complete planetary assembly.

Wheel Bearing Preload Setting Procedure



Figure 256

Measure thickness of clamp plate and record.



Figure 257

Install clamp plate.



Figure 258

Install (4) socket head screws and tighten evenly to 33.9 Nm [25 LBF/FT].



Figure 259

Shock axle shaft flange in several locations while rotating shaft.



Figure 260

Retighten screws to 33.9 Nm [25 LBF/FT]. Repeat shocking and torquing until screws no longer advance at 33.9 Nm [25 LBF/FT].

Initial Shim Pack Calculation

Remove (4) socket head screws and rotate clamp plate until holes in plate and shaft do not line up. Using depth gauge measure from top of clamp plate to end of axle shaft. Subtract thickness of clamp plate recorded in *figure 256* from depth measurement for initial shim thickness.

EXAMPLE:

Depth Measurement	21.2 mm [.83"]
Clamp Plate Thickness	22.6 mm [.88"]
Initial Shim Pack	1.4 mm [.050"]

Figure 261



Figure 262

Select an initial shim pack thickness from the calculation in *figure 261*.

NOTE: The original shim pack or 1.4 mm [.50"] may also be used as a starting point.



Figure 263

Install clamp plate, (4) socket head screws and shim pack.



Figure 264

Tighten (4) socket head screws evenly to 286-316 Nm [211-233 LBF/FT] while rotating axle shaft.



Figure 265

Rotate and shock shaft.



Figure 266

Measure rolling torque. Adjust shim pack thickness as required by repeating steps in *figures 262-266* to attain a rolling torque within 16-23 Nm [12-17 LBF/FT]. **NOTE:** Rolling torque must be returned to 0.0 before increasing shim pack thickness by shocking shaft after screws are loosened.



Figure 267

Remove (4) socket head screws, one at a time, apply Loctite 262 or equivalent and reinstall.



Figure 270

IMPORTANT: Large radius on bearing inner race must be installed down or towards the planet carrier.



Figure 268

Tighten (4) socket head screws evenly to 286-316 Nm [211-233 LBF/FT] while rotating axle shaft.



Figure 271

Install planet gear and bearing assembly.



Figure 269

Heat planet gear and bearing assembly. Reference bearing heating and freezing guidelines on *page 23*.



Figure 272

Install planet gear and bearing snap ring.



Figure 273

Turn snap ring in groove to verify that it is fully seated in groove. Repeat steps in **figures 269-273** for remaining (3) planet gears.



Figure 276

Install (12) dowel pins.



Figure 274

Install internal ring gear.



Figure 277

Install snap ring.

NOTE: If axle has brakes, snap ring is not used in this position, proceed to **figure 280**.



Figure 275

Align eye brows in ring gear with eye brows in trumpet arm.



Figure 278

Position snap ring ends between eye brows as shown.



Figure 279

Install sun gear. **NOTE:** This completes reassembly of trumpet arm on an axle without brakes. Repeat process for opposite trumpet arm.



Figure 282

Apply heavy coat "glob" of grease to (4) brake piston return springs and install. Install sun gear.



Figure 280

Install brake abutment plate aligning eye brows in plate with dowel pins. **NOTE:** If brake pistons have not been positioned on the differential assembly the abutment plate is needed for that procedure. Reference **figures 228-230** to align pistons.



Figure 283

Coat both sides of brake friction plate with axle lubricant and install.



Figure 281

Install snap ring. Center snap ring ends between eye brows in housing. Reference **figure 278**.




Figure 284

Install brake reaction plate. Repeat process for opposite trumpet arm.

Trumpet Arm Installation



Figure 285
Lubricate differential to
trumpet arm o-ring with grease.



Figure 286
Carefully stretch and install o-ring.



Figure 287
Install (2) alignment pins 180° apart.
IMPORTANT: Make sure brake pistons are properly
aligned prior to installing trumpet arm in the next
procedure. Reference **figures 228-230**.



Figure 288
Install trumpet arm assembly.
IMPORTANT: Trumpet arm should be pushed on by
hand. The only resistance should be from the brake
return springs as it makes contact with differential
housing. When released the piston return springs should
separate the housings slightly as shown in **figure 289**
indicating proper alignment.



Figure 289
Install (22) socket head screws and washers. Finger tighten
several only until housings are in full contact with each other.



Figure 290
Remove (2) alignment pins and install socket head screws
and washers.



Figure 291

Tighten (24) socket head screws to 286-316 Nm [211-233 LBF/FT].
Install level plug and tighten to 81-88 Nm [60-65 LBF/FT].
Repeat process for opposite trumpet arm.

Axle Air Test



Figure 292

Install axle air tester. This checking device is comprised of minimum 690 kPa [30 psi] air gauge, air shut off valve and regulator. Axle input pinion to be turned by hand (2) complete revolutions. Apply 83 kPa [12 psi] air pressure to axle assembly. Allow 30 second stabilization period. Lock off pressure. Monitor decay for 5 minutes. If excessive decay occurs 7 kPa [.1 psi]), disassemble axle and inspect for cause. Reassemble and retest. Install level plug and tighten to 81-88 Nm [60-65 LBF/FT].

Trunnion Mount Removal and Disassembly



Figure 293

Remove (12) front trunnion cap screws and washers.
Remove trunnion cap and shims.



Figure 296

Remove (14) socket head screws from front trunnion journal. **NOTE:** Remove screws and journal only if replacement is required.



Figure 294

Remove thrust washer.



Figure 297

Remove trunnion bracket if required.



Figure 295

Remove front trunnion.



Figure 298

Remove seal ring.



Figure 299
Remove radial bushing.



Figure 302
Remove inner seal ring.




Figure 300
Remove rear trunnion.
NOTE: Using appropriate puller remove trunnion sleeve if replacement is required.



Figure 303
Remove thrust washer.



Figure 301
Remove outer seal ring.



Figure 304
Remove radial bushing.

Trunnion Mount Reassembly and Installation



Figure 305

Install trunnion journal with (12) socket head screws and washers.



Figure 308

Install seal ring.



Figure 306

Tighten socket head screws to 286-3196 Nm [211-233 LBF/FT].



Figure 309

Install front trunnion.



Figure 307

Install radial bushing in front trunnion.



Figure 310

Install thrust washer. **IMPORTANT:** Laminated (yellow) surface must be towards trunnion cap.



Figure 311
Install original shims and trunnion cap with
(14) cap screws and washers.
Tighten to 99-107Nm [73-79LBF/FT].



Figure 314
Install thrust washer.
IMPORTANT: Laminated (yellow) surface must be
towards the differential center.



Figure 312
Install radial bushing in rear trunnion.



Figure 315
Install outer seal ring.



Figure 313
Install inner seal ring.




Figure 316
Install rear trunnion.



Figure 317

Install (1) Relief valve in recessed hole in rear trunnion and (1) relief valve in front trunnion cap.
Tighten to 19-22 Nm [14-16 LBF/FT].




Figure 318

Temporarily install grease fittings in the front and rear trunnions. Apply grease to fitting until it escapes from relief valves.

Replace grease fittings with pipe plugs and tighten to 19-22 Nm [14-16 LBF/FT].


NOTE: Trunnions should be greased at every normal servicing interval. Machines in conditions where the axle routinely becomes submerged should be serviced more often.

PINION GREASE SEAL AND WASHER DRIVER








PINION OIL SEAL DRIVER



INNER LIP SEAL DRIVER



OUTER LIP SEAL DRIVER




- ① SEAL DRIVER (OUTER LIP)
1 REQ'D
MATERIAL: 8620
CARB. .035-.045 DP
HARDEN Rc 50-55
HOT BLACK OXIDE

Technical drawing of a circular structure, likely a cross-section of a dome or a similar architectural element. The drawing includes a top view (left) and a side view (right).


Top View (Left): A circular structure with a central square. The square has a smaller square inside it, and the outer square has a smaller square inside it. The outer square is divided into four quadrants by dashed lines. The outer square is labeled with dimensions: 38 CENT (TYPE 12 UGS) and 30" (TYPE 12).

Side View (Right): A cross-section of the circular structure, showing a central square and radial lines. The side view is labeled with dimensions: 38 CENT (TYPE 12 UGS) and 30" (TYPE 12).



[illegible]

FLANGE WEAR SLEEVE DRIVER



© Copyright 2012 Dana Holding Corporation
All content is subject to copyright by Dana and may not
be reproduced in whole or in part by any means,
electronic or otherwise, without prior written approval.
THIS INFORMATION IS NOT INTENDED FOR SALE OR
RESALE, AND THIS NOTICE MUST REMAIN ON ALL
COPIES.

For product inquiries or support,
visit www.dana.com or call 419-887-6445
For other service publications,
visit www.SpicerParts.com/literature.asp
For online service parts ordering,
visit www.SpicerParts.com/order.asp



SPICER[®]
Off-Highway Products